



Set Up WorldStethoscope (WSN-3A)

Sensor Connector

- Black Line: Ground(-)
- Red Line: Power
- White Line: Probe(+)





Set one AA battery.


Insert earphones or an audio cable to PC.

Power Switch


Insert a sensor connector to this pins.

How to Use WorldStethoscope Morph


Drag from "Supplies" flap.




Push "Start" button to use WS morph.



Change category to "sound".



Use "frequency" and "level" tiles.



For example...

